



OPTICAL FIBER STRIPPER

ISO 9001 Certified

S218R Thermal Stripper

New & Improved!!

Cordless, Light, & Quick



Key Features

- Exceptional stripping for single and ribbon fiber.
- Simple Operation via built-in battery or AC power.
- Built-in battery recharger - battery always charging when AC power is connected.
- Durable Design
- Easy Maintenance on-Site
- RoHS Compliant

Specifications

Fiber Types	All fiber types, single to 12-fiber ribbons		
Clad Diameter	0.125mm		
Coating Diameter	0.25mm to 0.4mm for single fiber; 0.3mm to 0.4mm thickness for ribbons		
Power Source	DC 11 ~ 14V	AC 85 ~ 264V	* using S952 AC Adapter
Battery Running Time	Approximately 10 hrs.		
Charge Time	Approximately 2.5 hrs	* when unit is in off position	
Operating Environment	Temperature: 0 ~ 40 °C Humidity: Below 95% * non-condensing		
Dimensions/Weight	125W x 48D x 41H [mm], 260g		* weight including battery

Package & Accessories

Model	Item	Part Number	Qty	Note
S218R	Main Body	S218R-01	1	
	Battery	S944	1	
	AC Adapter	S952	1	
	Hexagon Wrench	S218X-07	2	For replacing blade
	Screwdriver	S218X-20	1	For battery cover
	Manual	----	1	
S218R Optional Parts	Power Cord A	S218X-02	1	Cord used to connect S218R to splicer
	Single Fiber Adapter	S218X-03	1	Used when stripping single fiber without a fiber holder
	Spare Blade	S218X-06	1	



Contact Us :

FURUKAWA ELECTRIC CO., LTD.

Head Office:

2-3, Marunouchi 2-chome,
Chiyoda-ku, Tokyo,
100-8322, Japan
TEL: + 81 3 3286 3227
FAX: + 81 3 3286 3978
www.furukawa.co.jp
fec.abr_opt_splicer@furukawaelectric.com

Europe:

Furukawa Electric Europe Ltd.
Furukawa House
77-85 Fulham Palace Road,
London W6 8JD, U.K.
Tel: + 44 (0) 20 7313 5300
Fax: + 44 (0) 20 7313 5310
www.furukawa.co.uk
splicers@furukawa.co.uk

North & South America:

OFS Fitel, LLC
2000 Northeast Expressway
Norcross, Georgia 30071, U.S.A
TOLL FREE: + 1 866 452 9516
Tel: + 1 678 783 1090
Fax: + 1 678 783 1093
www.ofsoptics.com
splicers@ofsoptics.com

China:

Furukawa Shanghai, Ltd.
Beijing Branch
Room 1108 Beijing Jing Guang
Center Hujialou Chaoyang District
Beijing 100020, China
Tel: + 86 10 8591 0608
Fax: + 86 10 8591 0609
www.furukawa-sh.cn

South East Asia:

Furukawa Electric Singapore
Pte. Ltd.
60 Albert Street, #13-10 OG
Albert Complex, Singapore
189969
Tel: + 65 6224 4686
Fax: + 65 6336 2635
comms@furukawa.com.sg